








MIJIA TRADING FZE

Tel/WhatsApp:00971-52-9121108 00971-52-8839474 00971-58-2283419

Email: longzeal@hotmail.com

NO.	Picture	Model	Price (AED)
1		start relay	75
2	<p>纯铜芯线减速起动机 动力之源</p> <p>齿数: 大10齿 功率: 8KW 电压: 24V</p>  <p>型号: QDJ2811-B 适用于: 斯太尔WD615、618系列 适用于斯太尔豪沃潍柴发动机</p>	Deceleration starter	730
3		MAN Engine fuse	58
4		Automotive starter motor	275/350/460
5	<p>曲轴转速传感器</p> <p>R61540090008</p> 	crankshaft speed sensor R61540090008	115
6		Compressor generator bracket VG1500130018A	208
7	 <p>重汽豪沃 油门回位弹簧 ZZ1167</p>	Throttle return spring	12

8	 <p>豪沃ZZ1167 喷油器总成</p>	Oil Injector Assembly	320
9		Electronic throttle assembly WG9725570010	230
10		Lubricating oil return pipe assembly VG1560070025	18
11		Engine computer board, onboard computer	220
12		Engine heat shield	620
13	 <p>中国重汽 全长20cm 粗10mm 豪沃发电机调整螺丝</p>	Generator adjustment screw	27
14	 <p>豪沃自动涨紧轮</p>	Automatic tensioning wheel	98/172/248

15	 <p>增压器连接软管 中冷器连接软管 空滤器连接软管</p> <p>重汽豪沃轻卡</p>	Hose	
16		Intake Pipe Assembly	470
17	 <p>图号: LG9704190528</p> <p>重汽豪沃轻卡进气引气管</p>	Air intake connecting pipe	120
18	 <p>豪沃ZZ1167 空调干燥瓶 空调储液罐</p>	Air conditioning drying bottle	125
19	 <p>重汽豪沃ZZ1167 空气干燥器</p>	Air Dryer	340
20	 <p>X30121</p>	escape-pipe	348
21	 <p>X10000698</p>	escape-pipe	366
22	 <p>SORL 瑞立集团瑞安汽车零部件有限公司 空气干燥器使用说明书</p>	dryer	60

23		Nitrogen oxygen sensor	600
24	<p>后处理真氮氧传感器</p> 	Nitrogen oxygen sensor	1120
25		Yuchai nitrogen oxygen sensor	1500
26		Water inlet pipe (short) VG1034130028	53
27		Water outlet pipe (long) VG1034130039	77
28	 <p>豪沃380豪瀚水泵回水管接头</p>	Howo engine water pipe joint	4x35
29	 <p>豪沃T7H豪瀚汕德卡水泵</p> <p>中国重汽MC曼发动机水泵</p>	Engine water pump accessories	1270

30		Thermostat core	126
31		differential pressure sensor New Model 21136 Old Model 21036	242/290
32	 <p>重汽水温传感器</p> <p>(国四 国五)</p> <p>豪沃380 豪沃T7H 豪沃T5G</p>	Water Temperature Sensor	60
33	 <p>中国重汽</p> <p>重汽豪沃(欧二 国三)</p> <p>水温感应塞</p>	Water Temperature Sensor	65